# ASUS®

## *USB Digital TV Stick*

# U3100mini/DVBT Plus

## Quick Start Guide

# 1.    Package contents

Check your U3100mini/DVBT Plus USB TV Stick package for the following items.

- U3100mini/DVBT Plus USB TV Stick x1
- Quick Start Guide x1
- Support CD x1
- Antenna x1
- Remote control x1
- Coaxial cable x1

**NOTE:** If any of the above items is damaged or missing, contact your retailer immediately.

# 2.    System requirements

Before using the U3100mini/DVBT Plus USB TV Stick, check if your system meets the following requirements:

- Windows® XP SP2 / Windows® Vista / Windows® 7
- Pentium® 4 2.0GHz CPU or above
- One free USB 2.0 port
- 512MB system memory or above
- AC97 compliant audio CODEC
- Microsoft® DirectX 9.0c
- Microsoft® DirectX 9.0c compliant graphics card / onboard GPU
- CD-ROM / DVD-ROM / BD-ROM drive
- 1GB free hard disk space for software installation

**For Windows® Media Center, Time shifting, and MPEG-2 capturing**

- Pentium® 4 3.0GHz CPU or equivalent AMD CPU
- Windows® Vista Premium
- 1024MB system memory or above
- Windows® Vista compliant audio CODEC
- Microsoft® DirectX 9.0c compliant graphics card / onboard GPU
- Microsoft® DirectX 9.0c
- Additional free hard disk space for recordings

    *\* Recording a one-hour program to an MPEG-2 file requires around 2.8GB hard disk space.*

- One free USB 2.0 port
- CD-ROM / DVD-ROM / BD-ROM drive

# 3.    Installing the software

To install the driver and utilities from the bundled Support CD:

1.    Place the Support CD into the optical drive. An autorun screen appears if **Autorun** is enabled on your computer.



2.    Select **Windows XP/Vista**, then click **Smart install wizard**. The auto installation wizard launches. Follow the onscreen instructions to complete the software installation.

> **NOTE:** The auto installation wizard installs all the driver and applications for your TV stick and synchronizes the TV country settings with your OS.

# 4.    Setting up the hardware

To connect your U3100mini/DVBT Plus USB TV Stick to other devices:

1.    Connect a digital TV antenna to the digital TV-in port on the USB TV stick. You may also connect a roof antenna to the USB TV stick via a coaxial cable.

2.    Plug the USB TV stick into a USB 2.0 port on your computer.



Digital TV-in port

Digital TV antenna

# 5. Remote control

**NOTE:** The remote control receiver is built in the USB TV stick.

## Layout



Stop

TV

Play / Pause

Rewind

Home

Enter/OK

Left

Volume up/down

Mute

Record

Close

Forward

Up

Back

Right

Down

Channel up/down

Fullscreen

Recall

# Key table

| Button | Mode | | | | | |
|---|---|---|---|---|---|---|
| | **TV** | **FM** | **DVD** | **VIDEO** | **PHOTO** | **MUSIC** |
| (TV mode icon) | TV mode | – | – | – | – | – |
| (Stop) | Stop | Stop | Stop | Stop | Stop | Stop |
| (Close) | Close | Close | Close | Close | Close | Close |
| (Rewind) | Rewind | Rewind | Rewind | Rewind | Rewind | Rewind |
| (Play/Pause) | Play/Pause | Play/Pause | Play/Pause | Play/Pause | Play/Pause | Play/Pause |
| (Forward) | Forward | Forward | Forward | Forward | Forward | Forward |
| (Home) | Back to main menu | Back to main menu | Back to main menu | Back to main menu | Back to main menu | Back to main menu |
| (Return) | Back to previous menu | Back to previous menu | Back to previous menu | Back to previous menu | Back to previous menu | Back to previous menu |
| CH +/- | Channel up/down | Search forward/backward | Next/previous chapter | – | – | – |
| VOL +/- | Volume up/down | Volume up/down | Volume up/down | Volume up/down | Volume up/down | Volume up/down |
| OK | Enter/OK | Enter/OK | Enter/OK | Enter/OK | Enter/OK | Enter/OK |
| ▲ | Up | Up | Up | Up | Up | Up |
| ▼ | Down | Down | Down | Down | Down | Down |
| ◄ | Left | Left | Left | Left | Left | Left |
| ► | Right | Right | Right | Right | Right | Right |
| (Fullscreen) | Fullscreen | Fullscreen | Fullscreen | Fullscreen | Fullscreen | Fullscreen |
| REC | Record | Record | Record | Record | Record | Record |
| MUTE | Mute | Mute | Mute | Mute | Mute | Mute |
| RECALL | Back to previous channel | – | – | – | – | – |

# 6.    Frequently Asked Questions (FAQs)

## What can I do if I get poor signal reception?

- Digital TV reception capability varies depending on your area. Use a roof antenna in low signal areas.
- Check if DVB-T TV is supported in your area.
- Mobile reception depends on the signal quality of your location.
- Check if your antenna is damaged or if it is connected properly.
- Reorient or relocate your antenna.
- Attach the antenna to metal.
- PCs/notebooks may cause harmful interference to radio or TV reception. Increase the separation between your PC/notebook and the TV stick using a USB extension cable to correct the interference.

## Do I need to adjust the TV country settings manually?

No. The auto installation wizard synchronizes the TV country settings with your OS automatically.